



Pistol Grip Installation

AML has an optional “pistol grip” style handle for users who prefer the point and shoot style. The pistol grip is secured to the unit by 4 screws. The battery is then relocated in the pistol grip for easy change-out.



Installing the Pistol Grip

To install the pistol grip, remove the pistol grip battery cover and store in a safe place. Remove the battery and set it aside. Remove only the 2 screws in the bottom of the battery compartment. The pistol grip comes with the necessary 4 screws to secure it to the unit. **Do not over-tighten the 4 screws.** Once the pistol grip is securely fastened, insert the battery into the bottom of the handle with the contacts towards the pistol grip. The battery is held into place by the spring latch. Install the pistol grip battery door on the bottom. Never use the pistol grip without the battery door in place.